

Results for 1140 Plett Rd

Analyte	Original Cyclopure Test Kit Results (collected 3/7/2025)	EGLE Lab Resampling Results (collected 6/24/2025)	Comparability Study Results (collected 9/10/2025)									
			Indoor*				Indoor, Flushed for 3 Minutes			Outdoor**		
			EGLE	EGLE Duplicate	Merit	Cyclopure	EGLE	Merit	Cyclopure	EGLE	Merit	Cyclopure
11Cl-PF3OUdS	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
4:2 FTS	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
6:2 FTS	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
8:2 FTS	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
9Cl-PF3ONS	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
ADONA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
HFPO-DA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
NFDHA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFBA	1.8	5	5	5	4	1.6	5	4	1.7	5	4	1.2
PFBS	22.9	28	28	29	24	22.5	29	27	24.6	28	26	24.2
PFDA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFDoA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFEESA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFHpA	3.1	4	4	4	3	3.6	4	4	3.7	4	4	3.4
PFHpS	1.3	ND	ND	ND	ND	1.9	ND	ND	1.6	ND	ND	1.9
PFHxA	4.5	6	5	5	5	4.5	5	6	3.9	5	5	3.4
PFHxS	24.3	35	36	39	29	31.7	35	29	32.6	37	28	31
PFMBA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFMPA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFNA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND
PFOA	19.3	34	34	35	22	21.4	35	30	21.4	35	24	20.3
PFOS	9.3	15	19	18	14	12.9	18	15	12.4	18	14	12.1
PFPeA	2.3	4	4	4	3	1.5	4	3	1.7	4	3	1.6
PFPeS	1.3	ND	2	2	ND	1.8	3	ND	1.8	2	ND	1.7
PFUnA	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND	ND

Results are in parts per trillion (ppt)

Samples were collected by AECOM staff under the guidance of Cyclopure and EGLE/MPART staff

*Indoor samples were collected without flushing the tap

**Outdoor samples were collected after flushing the tap for three minutes

All exceedances of Michigan Drinking Water Criteria are highlighted in yellow



**MICHIGAN DEPARTMENT OF
ENVIRONMENT, GREAT LAKES, AND ENERGY
ENVIRONMENTAL LABORATORY**

P.O. Box 30270
Lansing, MI 48909
TEL: (517) 335-9800
FAX: (517) 335-9600

Client ID: WT2509100804JLB-A

Lab ID: 2509147-05

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
Organics-Semivolatiles										
763051-92-9	11CI-PF3OUdS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
757124-72-4	4:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	IDA01
27619-97-2	6:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
39108-34-4	8:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
756426-58-1	9CI-PF3ONS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
919005-14-4	ADONA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
13252-13-6	HFPO-DA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
151772-58-6	NFDHA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-22-4	PFBA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-73-5	PFBS	28	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-76-2	PFDA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-55-1	PFDoA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
113507-82-7	PFEESA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-85-9	PFHpA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-92-8	PFHpS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-24-4	PFHxA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
355-46-4	PFHxS	36	2	ng/L	1	09/20/25	B5I2234	533	AA	
863090-89-5	PFMBA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
377-73-1	PFMPA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-95-1	PFNA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-67-1	PFOA	34	2	ng/L	1	09/20/25	B5I2234	533	AA	
1763-23-1	PFOS	19	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-90-3	PFPeA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-91-4	PFPeS	2	2	ng/L	1	09/20/25	B5I2234	533	AA	
2058-94-8	PFUnA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-4:2FTS			234 %	50-200		09/20/25	B5I2234	533	AA	IDA01
Isotope Dilution Analog: 13C2-6:2FTS			152 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-8:2FTS			157 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-PFDoA			118 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C2-PFOA			67.5 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-HFPODA			124 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C3-PFBA			52.2 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFBS			115 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFHxS			96.2 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFBA			128 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFHxA			96.7 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C4-PFOS			72.1 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFHxA			123 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFPeA			148 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C6-PFDA			106 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C7-PFUnA			112 %	50-200		09/20/25	B5I2234	533	AA	

Client ID: WT2509100804JLB-A

Lab ID: 2509147-05

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
-------	---------	--------	----	-------	----------	------------------	----------	--------	---------	-----------

Organics-Semivolatiles

	<i>Isotope Dilution Analog: 13C8-PFOA</i>		110 %	50-200		09/20/25	B5I2234	533	AA	
	<i>Isotope Dilution Analog: 13C8-PFOS</i>		111 %	50-200		09/20/25	B5I2234	533	AA	
	<i>Isotope Dilution Analog: 13C9-PFNA</i>		143 %	50-200		09/20/25	B5I2234	533	AA	

Client ID: WT2509100804JLB-A-DUP

Lab ID: 2509147-06

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
Organics-Semivolatiles										
763051-92-9	11CI-PF3OUdS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
757124-72-4	4:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	IDA01
27619-97-2	6:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
39108-34-4	8:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
756426-58-1	9CI-PF3ONS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
919005-14-4	ADONA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
13252-13-6	HFPO-DA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
151772-58-6	NFDHA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-22-4	PFBA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-73-5	PFBS	29	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-76-2	PFDA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-55-1	PFDoA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
113507-82-7	PFEESA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-85-9	PFHpA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-92-8	PFHpS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-24-4	PFHxA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
355-46-4	PFHxS	39	2	ng/L	1	09/20/25	B5I2234	533	AA	
863090-89-5	PFMBA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
377-73-1	PFMPA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-95-1	PFNA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-67-1	PFOA	35	2	ng/L	1	09/20/25	B5I2234	533	AA	
1763-23-1	PFOS	18	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-90-3	PFPeA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-91-4	PFPeS	2	2	ng/L	1	09/20/25	B5I2234	533	AA	
2058-94-8	PFUnA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-4:2FTS			236 %	50-200		09/20/25	B5I2234	533	AA	IDA01
Isotope Dilution Analog: 13C2-6:2FTS			143 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-8:2FTS			160 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-PFDoA			120 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C2-PFOA			74.5 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-HFPODA			119 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C3-PFBA			54.5 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFBS			109 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFHxS			89.4 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFBA			125 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFHpA			93.9 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C4-PFOS			78.2 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFHxA			124 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFPeA			144 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C6-PFDA			106 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C7-PFUnA			113 %	50-200		09/20/25	B5I2234	533	AA	

Client ID: WT2509100804JLB-A-DUP

Lab ID: 2509147-06

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
-------	---------	--------	----	-------	----------	------------------	----------	--------	---------	-----------

Organics-Semivolatiles

<i>Isotope Dilution Analog: 13C8-PFOA</i>			104 %		50-200	09/20/25	B512234	533	AA	
<i>Isotope Dilution Analog: 13C8-PFOS</i>			109 %		50-200	09/20/25	B512234	533	AA	
<i>Isotope Dilution Analog: 13C9-PFNA</i>			128 %		50-200	09/20/25	B512234	533	AA	

Client ID: WT2509100851JLB-C

Lab ID: 2509147-09

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
Organics-Semivolatiles										
763051-92-9	11Cl-PF3OUdS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
757124-72-4	4:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	IDA01
27619-97-2	6:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
39108-34-4	8:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
756426-58-1	9Cl-PF3ONS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
919005-14-4	ADONA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
13252-13-6	HFPO-DA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
151772-58-6	NFDHA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-22-4	PFBA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-73-5	PFBS	29	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-76-2	PFDA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-55-1	PFDoA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
113507-82-7	PFEESA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-85-9	PFHpA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-92-8	PFHpS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-24-4	PFHxA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
355-46-4	PFHxS	35	2	ng/L	1	09/20/25	B5I2234	533	AA	
863090-89-5	PFMBA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
377-73-1	PFMPA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-95-1	PFNA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-67-1	PFOA	35	2	ng/L	1	09/20/25	B5I2234	533	AA	
1763-23-1	PFOS	18	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-90-3	PFPeA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-91-4	PFPeS	3	2	ng/L	1	09/20/25	B5I2234	533	AA	
2058-94-8	PFUnA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-4:2FTS		221 %		50-200		09/20/25	B5I2234	533	AA	IDA01
Isotope Dilution Analog: 13C2-6:2FTS		135 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-8:2FTS		153 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-PFDoA		104 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C2-PFOA		79.8 %		50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-HFPODA		103 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C3-PFBA		53.8 %		50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFBS		107 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFHxS		92.9 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFBA		119 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFHxA		93.8 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C4-PFOS		78.1 %		50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFHxA		111 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFPeA		141 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C6-PFDA		83.0 %		50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C7-PFUnA		95.0 %		50-200		09/20/25	B5I2234	533	AA	

Client ID: WT2509100851JLB-C

Lab ID: 2509147-09

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
-------	---------	--------	----	-------	----------	------------------	----------	--------	---------	-----------

Organics-Semivolatiles

	<i>Isotope Dilution Analog: 13C8-PFOA</i>		96.7 %		50-200	09/20/25	B512234	533	AA	
	<i>Isotope Dilution Analog: 13C8-PFOS</i>		105 %		50-200	09/20/25	B512234	533	AA	
	<i>Isotope Dilution Analog: 13C9-PFNA</i>		104 %		50-200	09/20/25	B512234	533	AA	

Client ID: WT2509100821JLB-B

Lab ID: 2509147-07

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
Organics-Semivolatiles										
763051-92-9	11Cl-PF3OUdS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
757124-72-4	4:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	IDA01
27619-97-2	6:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
39108-34-4	8:2FTS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
756426-58-1	9Cl-PF3ONS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
919005-14-4	ADONA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
13252-13-6	HFPO-DA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
151772-58-6	NFDHA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-22-4	PFBA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-73-5	PFBS	28	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-76-2	PFDA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-55-1	PFDoA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
113507-82-7	PFEESA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-85-9	PFHpA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-92-8	PFHpS	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
307-24-4	PFHxA	5	2	ng/L	1	09/20/25	B5I2234	533	AA	
355-46-4	PFHxS	37	2	ng/L	1	09/20/25	B5I2234	533	AA	
863090-89-5	PFMBA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
377-73-1	PFMPA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
375-95-1	PFNA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
335-67-1	PFOA	35	2	ng/L	1	09/20/25	B5I2234	533	AA	
1763-23-1	PFOS	18	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-90-3	PFPeA	4	2	ng/L	1	09/20/25	B5I2234	533	AA	
2706-91-4	PFPeS	2	2	ng/L	1	09/20/25	B5I2234	533	AA	
2058-94-8	PFUnA	ND	2	ng/L	1	09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-4:2FTS			232 %	50-200		09/20/25	B5I2234	533	AA	IDA01
Isotope Dilution Analog: 13C2-6:2FTS			141 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-8:2FTS			160 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C2-PFDoA			125 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C2-PFOA			76.1 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-HFPODA			109 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C3-PFBA			54.6 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFBS			108 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C3-PFHxS			95.9 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFBA			121 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C4-PFHxA			105 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Performance Standard: 13C4-PFOS			74.9 %	50-150		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFHxA			118 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C5-PFPeA			137 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C6-PFDA			110 %	50-200		09/20/25	B5I2234	533	AA	
Isotope Dilution Analog: 13C7-PFUnA			121 %	50-200		09/20/25	B5I2234	533	AA	

Client ID: WT2509100821JLB-B

Lab ID: 2509147-07

CAS #	Analyte	Result	RL	Units	Dilution	Analyzed Date	QC Batch	Method	Analyst	Qualifier
-------	---------	--------	----	-------	----------	------------------	----------	--------	---------	-----------

Organics-Semivolatiles

<i>Isotope Dilution Analog: 13C8-PFOA</i>			108 %	50-200		09/20/25	B5I2234	533	AA	
<i>Isotope Dilution Analog: 13C8-PFOS</i>			112 %	50-200		09/20/25	B5I2234	533	AA	
<i>Isotope Dilution Analog: 13C9-PFNA</i>			129 %	50-200		09/20/25	B5I2234	533	AA	



Analytical Laboratory Report

Attachment 3

Lab Sample ID: S78729.22

Sample Tag: WT2509100807JLB-A

Collected Date/Time: 09/10/2025 08:07

Matrix: Drinking Water

COC Reference: 3

Sample Containers

#	Type	Preservative(s)	Refrigerated?	Arrival Temp. (C)	Thermometer #
3	250mL Plastic	Ammonium Acetate	Yes	6.0	IR

Extraction / Prep.

Parameter	Result	Method	Run Date	Analyst	Flags
Sample Amount*	279.70 ml	E533	09/16/25 10:00	PTW	
pH check for DW PFAs*	6	N/A	09/16/25 10:00	PTW	

Organics

PFAs Drinking Water, Method: E533, Run Date: 09/22/25 16:43, Analyst: KYD

Parameter	Result	RL	MDL	Units	Dilution	CAS#	Flags	Limits
PFHxA	5	2		ng/L	1	307-24-4		400,000
PFBS	24	2		ng/L	1	375-73-5		420
PFHpA	3	2		ng/L	1	375-85-9		
PFOA	22	2		ng/L	1	335-67-1	!	8
PFHxS	29	2		ng/L	1	355-46-4		51
PFNA	Not detected	2		ng/L	1	375-95-1		6
PFDA	Not detected	2		ng/L	1	335-76-2		
PFOS	14	2		ng/L	1	1763-23-1		16
PFUnDA	Not detected	2		ng/L	1	2058-94-8		
PFDoDA	Not detected	2		ng/L	1	307-55-1		
11CI-PF3OUdS	Not detected	2		ng/L	1	763051-92-9		
9CI-PF3ONS	Not detected	2		ng/L	1	756426-58-1		
ADONA	Not detected	2		ng/L	1	919005-14-4		
HFPO-DA	Not detected	2		ng/L	1	13252-13-6		370
NFDHA	Not detected	2		ng/L	1	151772-58-6		
PFBA	4	2		ng/L	1	375-22-4		
8:2 FTSA*	Not detected	2		ng/L	1	39108-34-4		
PFEESA	Not detected	2		ng/L	1	113507-82-7		
PFHpS	Not detected	2		ng/L	1	375-92-8		
4:2 FTSA*	Not detected	2		ng/L	1	757124-72-4		
PFMBA	Not detected	2		ng/L	1	863090-89-5		
PFMPA	Not detected	2		ng/L	1	377-73-1		
6:2 FTSA*	Not detected	2		ng/L	1	27619-97-2		
PFPeA	3	2		ng/L	1	2706-90-3		
PFPeS	Not detected	2		ng/L	1	2706-91-4		

!-Result is outside of stated limit criteria



Analytical Laboratory Report

Lab Sample ID: S78729.25
Sample Tag: WT2509100852JLB-C
Collected Date/Time: 09/10/2025 08:52
Matrix: Drinking Water
COC Reference: 3

Sample Containers

#	Type	Preservative(s)	Refrigerated?	Arrival Temp. (C)	Thermometer #
3	250mL Plastic	Ammonium Acetate	Yes	6.0	IR

Extraction / Prep.

Parameter	Result	Method	Run Date	Analyst	Flags
Sample Amount*	277.89 ml	E533	09/16/25 10:00	PTW	
pH check for DW PFAs*	6	N/A	09/16/25 10:00	PTW	

Organics

PFAs Drinking Water, Method: E533, Run Date: 09/17/25 16:50, Analyst: KYD

Parameter	Result	RL	MDL	Units	Dilution	CAS#	Flags	Limits
PFHxA	6	2		ng/L	1	307-24-4		400,000
PFBS	27	2		ng/L	1	375-73-5		420
PFHpA	4	2		ng/L	1	375-85-9		
PFOA	30	2		ng/L	1	335-67-1	!	8
PFHxS	29	2		ng/L	1	355-46-4		51
PFNA	Not detected	2		ng/L	1	375-95-1		6
PFDA	Not detected	2		ng/L	1	335-76-2		
PFOS	15	2		ng/L	1	1763-23-1		16
PFUnDA	Not detected	2		ng/L	1	2058-94-8		
PFDoDA	Not detected	2		ng/L	1	307-55-1		
11CI-PF3OUdS	Not detected	2		ng/L	1	763051-92-9		
9CI-PF3ONS	Not detected	2		ng/L	1	756426-58-1		
ADONA	Not detected	2		ng/L	1	919005-14-4		
HFPO-DA	Not detected	2		ng/L	1	13252-13-6		370
NFDHA	Not detected	2		ng/L	1	151772-58-6		
PFBA	4	2		ng/L	1	375-22-4		
8:2 FTSA*	Not detected	2		ng/L	1	39108-34-4		
PFEESA	Not detected	2		ng/L	1	113507-82-7		
PFHpS	Not detected	2		ng/L	1	375-92-8		
4:2 FTSA*	Not detected	2		ng/L	1	757124-72-4		
PFMBA	Not detected	2		ng/L	1	863090-89-5		
PFMPA	Not detected	2		ng/L	1	377-73-1		
6:2 FTSA*	Not detected	2		ng/L	1	27619-97-2		
PFPeA	3	2		ng/L	1	2706-90-3		
PFPeS	Not detected	2		ng/L	1	2706-91-4		

!-Result is outside of stated limit criteria



Analytical Laboratory Report

Lab Sample ID: S78729.23

Sample Tag: WT2509100824JLB-B

Collected Date/Time: 09/10/2025 08:24

Matrix: Drinking Water

COC Reference: 3

Sample Containers

#	Type	Preservative(s)	Refrigerated?	Arrival Temp. (C)	Thermometer #
3	250mL Plastic	Ammonium Acetate	Yes	6.0	IR

Extraction / Prep.

Parameter	Result	Method	Run Date	Analyst	Flags
Sample Amount*	287.66 ml	E533	09/16/25 10:00	PTW	
pH check for DW PFAs*	6	N/A	09/16/25 10:00	PTW	

Organics

PFAs Drinking Water, Method: E533, Run Date: 09/17/25 16:05, Analyst: KYD

Parameter	Result	RL	MDL	Units	Dilution	CAS#	Flags	Limits
PFHxA	5	2		ng/L	1	307-24-4		400,000
PFBS	26	2		ng/L	1	375-73-5		420
PFHpA	4	2		ng/L	1	375-85-9		
PFOA	24	2		ng/L	1	335-67-1	!	8
PFHxS	28	2		ng/L	1	355-46-4		51
PFNA	Not detected	2		ng/L	1	375-95-1		6
PFDA	Not detected	2		ng/L	1	335-76-2		
PFOS	14	2		ng/L	1	1763-23-1		16
PFUnDA	Not detected	2		ng/L	1	2058-94-8		
PFDoDA	Not detected	2		ng/L	1	307-55-1		
11CI-PF3OUdS	Not detected	2		ng/L	1	763051-92-9		
9CI-PF3ONS	Not detected	2		ng/L	1	756426-58-1		
ADONA	Not detected	2		ng/L	1	919005-14-4		
HFPO-DA	Not detected	2		ng/L	1	13252-13-6		370
NFDHA	Not detected	2		ng/L	1	151772-58-6		
PFBA	4	2		ng/L	1	375-22-4		
8:2 FTSA*	Not detected	2		ng/L	1	39108-34-4		
PFEESA	Not detected	2		ng/L	1	113507-82-7		
PFHpS	Not detected	2		ng/L	1	375-92-8		
4:2 FTSA*	Not detected	2		ng/L	1	757124-72-4		
PFMBA	Not detected	2		ng/L	1	863090-89-5		
PFMPA	Not detected	2		ng/L	1	377-73-1		
6:2 FTSA*	Not detected	2		ng/L	1	27619-97-2		
PFPeA	3	2		ng/L	1	2706-90-3		
PFPeS	Not detected	2		ng/L	1	2706-91-4		

!-Result is outside of stated limit criteria



Water Test Kit Pro Results Report

710 Clark Street Suite 350, Evanston, IL 60201 | cyclopure.com

To: EGLERRD

Date: October 7, 2025

Thanks for testing your water with us! We test for 55 PFAS compounds. PFAS detects are highlighted in yellow. Concentrations are shown in parts per trillion (ppt). Our limit of quantification (LOQ) is 1.0 ppt for each of the 55 PFAS. We do not report detection values below our LOQ.

Your report lists results for each of the EPA regulated PFAS6 compounds (PFOA, PFOS, PFHxS, PFNA, GenX, and PFBS). Values are reported under Additional PFAS for the other 49 PFAS tested only if there has been a detection above 1.0 ppt. Regulatory information for the PFAS6 is located on the next page.

What's In My Water?

Kit# 23669. We found 10 PFAS in this water sample, with a total concentration of 103.4 ppt.

Barcode	WTK_PFAS_23669
Name	EGLERRD
Location	Cadillac, MI 49601
Street Address	1140 Plett Rd, Elevation Distribution LLC
Latitude	44.26535
Longitude	-85.39541
Comments	Well Water; No treatment, no flush, kitchen sink sample; 44.26535; 85.39541; 1140 Plett Rd, Elevation Distribution LLC
Sampling Date	9/10/25 8:00
Order Number	SO1710
PFOA	21.4
PFOS	12.9
PFHxS	31.7
PFNA	< 1.0 ppt
GenX	< 1.0 ppt
PFBS	22.5
Total PFAS (EPA PFAS6)	88.5
Additional PFAS	
PFBA	1.6
PFPeA	1.5
PFHxA	4.5
PFHpA	3.6
PFPeS	1.8
PFHpS	1.9
6:2 FTS	< 1.0 ppt
FBSA	< 1.0 ppt
Total PFAS (All Detected)	103.4



Our Lab Method

Back at the lab, PFAS compounds collected by the extraction disk are eluted and analyzed using isotope dilution HPLC-MS/MS.

Regulatory Information

EPA has set Maximum Contaminant Level Goals (MCLGs) for each of the PFAS6 compounds. The MCLG is the maximum level for a contaminant in drinking water below which there is no known or expected risk to health, allowing for an adequate margin of safety. MCLGs are non-enforceable public health goals. EPA has set MCLGs of zero for PFOA and PFOS. This reflects the latest science showing that there is no level of exposure to these two PFAS without risk of health impacts. For PFBS, we have listed the EPA's health based value (HBV). [\[Click here to learn more\]](#).

Compound	Final MCLG	Final MCL (enforceable levels)
PFOA	Zero	4.0 ppt
PFOS	Zero	4.0 ppt
PFHxS	10 ppt	10 ppt
PFNA	10 ppt	10 ppt
HFPO-DA (GenX)	10 ppt	10 ppt
PFBS	2000 ppt*	Hazard Index

* EPA health-based value.

55 PFAS Compounds Detected by Cyclopure Analytical Methods

Compound	Abbreviation	CAS#
Perfluorobutanoic Acid	PFBA	375-22-4
Perfluoropentanoic Acid	PFPeA	2706-90-3
Perfluorohexanoic Acid	PFHxA	307-24-4
Perfluoroheptanoic Acid	PFHpA	375-85-9
Perfluorooctanoic Acid	PFOA	335-67-1
Perfluorononanoic Acid	PFNA	375-95-1
Perfluorodecanoic Acid	PFDA	335-76-2
Perfluoroundecanoic Acid	PFUnA	2058-94-8
Perfluorododecanoic Acid	PFDoA	307-55-1
Perfluorotridecanoic Acid	PFTTrDA	72629-94-8
Perfluorotetradecanoic Acid	PFTeA	376-06-7
Perfluoropropane Sulfonic Acid	PFPrS	423-41-6
Perfluorobutane Sulfonic Acid	PFBS	375-73-5
Perfluoropentane Sulfonic Acid	PFPeS	2706-91-4
Perfluorohexane Sulfonic Acid	PFHxS	355-46-4
Perfluoroheptane Sulfonic Acid	PFHpS	375-92-8
Perfluorooctane Sulfonic Acid	PFOS	1763-23-1
Perfluorononane Sulfonic Acid	PFNS	474511-07-4
Perfluorodecane Sulfonic Acid	PFDS	335-77-3
Perfluorododecane Sulfonic Acid	PFDoS	79780-39-5
4:2 Fluorotelomer Sulfonate	4:2 FTS	414911-30-1
6:2 Fluorotelomer Sulfonate	6:2 FTS	425670-75-3
8:2 Fluorotelomer Sulfonate	8:2 FTS	481071-78-7
10:2 Fluorotelomer Sulfonate	10:2 FTS	120226-60-0
Perfluorobutane Sulfonamide	FBSA	30334-69-1

N-Methylperfluorobutanesulfonamide	MeFBSA	68298-12-4
Perfluorohexane Sulfonamide	FHxSA	41997-13-1
Perfluorooctane Sulfonamide	PFOSA	754-91-6
Perfluorodecane Sulfonamide	FDSA	N/A
N-Ethylperfluorooctane-1-Sulfonamide	NEtFOSA	4151-50-2
N-Methylperfluorooctane-1-Sulfonamide	NMeFOSA	31506-32-8
Perfluorooctane Sulfonamido Acetic Acid	FOSAA	2806-24-8
N-Ethyl Perfluorooctane Sulfonamido Acetic Acid	NEtFOSAA	2991-50-6
N-Methyl Perfluorooctane Sulfonamido Acetic Acid	NMeFOSAA	2355-31-9
N-methyl perfluorooctanesulfonamidoethanol	NMeFOSE	24448-09-7
N-ethyl perfluorooctanesulfonamidoethanol	NEtFOSE	1691-99-2
Hexafluoropropylene Oxide Dimer Acid	HFPO-DA	13252-13-6
4,8-Dioxa-3H-Perfluorononanoate	ADONA	919005-14-4
Perfluoro-3-Methoxypropanoic Acid	PFMPA	377-73-1
Perfluoro-4-Methoxybutanoic Acid	PFMBA	863090-89-5
Perfluoro-3,6-Dioxaheptanoic Acid	NFDHA	151772-58-6
9-Chlorohexadecafluoro-3-Oxanone-1-Sulfonic Acid	9Cl-PF3ONS	756426-58-1
11-Chloroeicosafluoro-3-Oxanonane-1-Sulfonic Acid	11Cl-PF30UdS	763051-92-9
Perfluoro(2-ethoxyethane) Sulfonic acid	PFEESA	113507-82-7
Perfluoro-4-ethylcyclohexane Sulfonic Acid	PFECHS	646-83-3
8-Chloroperfluoro-1-Octanesulfonic Acid	8Cl-PFOS	777011-38-8
3-Perfluoropropyl Propanoic Acid	3:3FTCA	356-02-5
2h,2h,3h,3h-Perfluorooctanoic Acid	5:3FTCA	914637-49-3
3-Perfluoroheptyl propanoic acid	7:3FTCA	812-70-4
2H-Perfluoro-2-dodecenoic acid	FDUEA	70887-94-4
2H-perfluoro-2-decenoic acid	FOUEA	70887-84-2
Bis(perfluorohexyl)phosphinic acid	6:6PFPI	40143-77-9
(Heptadecafluorooctyl)(tridecafluorohexyl) Phosphinic Acid	6:8PFPI	610800-34-5
Bis(perfluorooctyl)phosphinic acid	8:8PFPI	40143-79-1
N-(3-dimethylaminopropan-1-yl) perfluoro-1-hexanesulfonamide	N-AP-FHxSA	50598-28-2

To: EGLERRD

Date: October 7, 2025

Thanks for testing your water with us! We test for 55 PFAS compounds. PFAS detects are highlighted in yellow. Concentrations are shown in parts per trillion (ppt). Our limit of quantification (LOQ) is 1.0 ppt for each of the 55 PFAS. We do not report detection values below our LOQ.

Your report lists results for each of the EPA regulated PFAS6 compounds (PFOA, PFOS, PFHxS, PFNA, GenX, and PFBS). Values are reported under Additional PFAS for the other 49 PFAS tested only if there has been a detection above 1.0 ppt. Regulatory information for the PFAS6 is located on the next page.

What's In My Water?

Kit# 23671. We found 10 PFAS in this water sample, with a total concentration of 105.4 ppt.

Barcode	WTK_PFAS_23671
Name	EGLERRD
Location	Cadillac, MI 49601
Street Address	1140 Plett Rd, Elevation Distribution LLC
Latitude	44.26535
Longitude	-85.39541
Comments	Well Water; Kitchen sink (no treatment) after 3 min flush; 44.26535; 85.39541; 1140 Plett Rd, Elevation Distribution LLC
Sampling Date	9/10/25 8:50
Order Number	SO1710
PFOA	21.4
PFOS	12.4
PFHxS	32.6
PFNA	< 1.0 ppt
GenX	< 1.0 ppt
PFBS	24.6
Total PFAS (EPA PFAS6)	91
Additional PFAS	
PFBA	1.7
PFPeA	1.7
PFHxA	3.9
PFHpA	3.7
PFPeS	1.8
PFHpS	1.6
6:2 FTS	< 1.0 ppt
FBSA	< 1.0 ppt
Total PFAS (All Detected)	105.4

Regulatory Information

EPA has set Maximum Contaminant Level Goals (MCLGs) for each of the PFAS6 compounds. The MCLG is the maximum level for a contaminant in drinking water below which there is no known or expected risk to health, allowing for an adequate margin of safety. MCLGs are non-enforceable public health goals. EPA has set MCLGs of zero for PFOA and PFOS. This reflects the latest science showing that there is no level of exposure to these two PFAS without risk of health impacts. For PFBS, we have listed the EPA's health based value (HBV). [\[Click here to learn more\]](#).

Compound	Final MCLG	Final MCL (enforceable levels)
PFOA	Zero	4.0 ppt
PFOS	Zero	4.0 ppt
PFHxS	10 ppt	10 ppt
PFNA	10 ppt	10 ppt
HFPO-DA (GenX)	10 ppt	10 ppt
PFBS	2000 ppt*	Hazard Index

* EPA health-based value.

55 PFAS Compounds Detected by Cyclopure Analytical Methods

Compound	Abbreviation	CAS#
Perfluorobutanoic Acid	PFBA	375-22-4
Perfluoropentanoic Acid	PFPeA	2706-90-3
Perfluorohexanoic Acid	PFHxA	307-24-4
Perfluoroheptanoic Acid	PFHpA	375-85-9
Perfluorooctanoic Acid	PFOA	335-67-1
Perfluorononanoic Acid	PFNA	375-95-1
Perfluorodecanoic Acid	PFDA	335-76-2
Perfluoroundecanoic Acid	PFUnA	2058-94-8
Perfluorododecanoic Acid	PFDaA	307-55-1
Perfluorotridecanoic Acid	PFTTrDA	72629-94-8
Perfluorotetradecanoic Acid	PFTeA	376-06-7
Perfluoropropane Sulfonic Acid	PFPrS	423-41-6
Perfluorobutane Sulfonic Acid	PFBS	375-73-5
Perfluoropentane Sulfonic Acid	PFPeS	2706-91-4
Perfluorohexane Sulfonic Acid	PFHxS	355-46-4
Perfluoroheptane Sulfonic Acid	PFHpS	375-92-8
Perfluorooctane Sulfonic Acid	PFOS	1763-23-1
Perfluorononane Sulfonic Acid	PFNS	474511-07-4
Perfluorodecane Sulfonic Acid	PFDS	335-77-3
Perfluorododecane Sulfonic Acid	PFDoS	79780-39-5
4:2 Fluorotelomer Sulfonate	4:2 FTS	414911-30-1
6:2 Fluorotelomer Sulfonate	6:2 FTS	425670-75-3
8:2 Fluorotelomer Sulfonate	8:2 FTS	481071-78-7
10:2 Fluorotelomer Sulfonate	10:2 FTS	120226-60-0
Perfluorobutane Sulfonamide	FBSA	30334-69-1

N-Methylperfluorobutanesulfonamide	MeFBSA	68298-12-4
Perfluorohexane Sulfonamide	FHxSA	41997-13-1
Perfluorooctane Sulfonamide	PFOSA	754-91-6
Perfluorodecane Sulfonamide	FDSA	N/A
N-Ethylperfluorooctane-1-Sulfonamide	NEtFOSA	4151-50-2
N-Methylperfluorooctane-1-Sulfonamide	NMeFOSA	31506-32-8
Perfluorooctane Sulfonamido Acetic Acid	FOSAA	2806-24-8
N-Ethyl Perfluorooctane Sulfonamido Acetic Acid	NEtFOSAA	2991-50-6
N-Methyl Perfluorooctane Sulfonamido Acetic Acid	NMeFOSAA	2355-31-9
N-methyl perfluorooctanesulfonamidoethanol	NMeFOSE	24448-09-7
N-ethyl perfluorooctanesulfonamidoethanol	NEtFOSE	1691-99-2
Hexafluoropropylene Oxide Dimer Acid	HFPO-DA	13252-13-6
4,8-Dioxa-3H-Perfluorononanoate	ADONA	919005-14-4
Perfluoro-3-Methoxypropanoic Acid	PFMPA	377-73-1
Perfluoro-4-Methoxybutanoic Acid	PFMBA	863090-89-5
Perfluoro-3,6-Dioxaheptanoic Acid	NFDHA	151772-58-6
9-Chlorohexadecafluoro-3-Oxanone-1-Sulfonic Acid	9CI-PF3ONS	756426-58-1
11-Chloroeicosafluoro-3-Oxanonane-1-Sulfonic Acid	11CL-PF3OUdS	763051-92-9
Perfluoro(2-ethoxyethane) Sulfonic acid	PFEESA	113507-82-7
Perfluoro-4-ethylcyclohexane Sulfonic Acid	PFECHS	646-83-3
8-Chloroperfluoro-1-Octanesulfonic Acid	8CI-PFOS	777011-38-8
3-Perfluoropropyl Propanoic Acid	3:3FTCA	356-02-5
2h,2h,3h,3h-Perfluorooctanoic Acid	5:3FTCA	914637-49-3
3-Perfluoroheptyl propanoic acid	7:3FTCA	812-70-4
2H-Perfluoro-2-dodecenoic acid	FDUEA	70887-94-4
2H-perfluoro-2-decenoic acid	FOUEA	70887-84-2
Bis(perfluorohexyl)phosphinic acid	6:6PFPI	40143-77-9
(Heptadecafluorooctyl)(tridecafluorohexyl) Phosphinic Acid	6:8PFPI	610800-34-5
Bis(perfluorooctyl)phosphinic acid	8:8PFPI	40143-79-1
N-(3-dimethylaminopropan-1-yl) perfluoro-1-hexanesulfonamide	N-AP-FHxSA	50598-28-2

To: EGLERRD

Date: October 7, 2025

Thanks for testing your water with us! We test for 55 PFAS compounds. PFAS detects are highlighted in yellow. Concentrations are shown in parts per trillion (ppt). Our limit of quantification (LOQ) is 1.0 ppt for each of the 55 PFAS. We do not report detection values below our LOQ.

Your report lists results for each of the EPA regulated PFAS6 compounds (PFOA, PFOS, PFHxS, PFNA, GenX, and PFBS). Values are reported under Additional PFAS for the other 49 PFAS tested only if there has been a detection above 1.0 ppt. Regulatory information for the PFAS6 is located on the next page.

What's In My Water?

Kit# 23670. We found 10 PFAS in this water sample, with a total concentration of 100.8 ppt.

Barcode	WTK_PFAS_23670
Name	EGLERRD
Location	Cadillac, MI 49601
Street Address	1140 Plett Rd, Elevation Distribution LLC
Latitude	44.26535
Longitude	-85.39541
Comments	Well Water; Outdoor spigot, 3 min flushed (no treatment); 44.26535; 85.39541; 1140 Plett Rd (Elevation \Distribution LLC)
Sampling Date	9/10/25 8:19
Order Number	SO1710
PFOA	20.3
PFOS	12.1
PFHxS	31
PFNA	< 1.0 ppt
GenX	< 1.0 ppt
PFBS	24.2
Total PFAS (EPA PFAS6)	87.6
Additional PFAS	
PFBA	1.2
PFPeA	1.6
PFHxA	3.4
PFHpA	3.4
PFPeS	1.7
PFHpS	1.9
6:2 FTS	< 1.0 ppt
FBSA	< 1.0 ppt
Total PFAS (All Detected)	100.8

Regulatory Information

EPA has set Maximum Contaminant Level Goals (MCLGs) for each of the PFAS6 compounds. The MCLG is the maximum level for a contaminant in drinking water below which there is no known or expected risk to health, allowing for an adequate margin of safety. MCLGs are non-enforceable public health goals. EPA has set MCLGs of zero for PFOA and PFOS. This reflects the latest science showing that there is no level of exposure to these two PFAS without risk of health impacts. For PFBS, we have listed the EPA's health based value (HBV). [\[Click here to learn more\]](#).

Compound	Final MCLG	Final MCL (enforceable levels)
PFOA	Zero	4.0 ppt
PFOS	Zero	4.0 ppt
PFHxS	10 ppt	10 ppt
PFNA	10 ppt	10 ppt
HFPO-DA (GenX)	10 ppt	10 ppt
PFBS	2000 ppt*	Hazard Index

* EPA health-based value.

55 PFAS Compounds Detected by Cyclopure Analytical Methods

Compound	Abbreviation	CAS#
Perfluorobutanoic Acid	PFBA	375-22-4
Perfluoropentanoic Acid	PFPeA	2706-90-3
Perfluorohexanoic Acid	PFHxA	307-24-4
Perfluoroheptanoic Acid	PFHpA	375-85-9
Perfluorooctanoic Acid	PFOA	335-67-1
Perfluorononanoic Acid	PFNA	375-95-1
Perfluorodecanoic Acid	PFDA	335-76-2
Perfluoroundecanoic Acid	PFUnA	2058-94-8
Perfluorododecanoic Acid	PFDaA	307-55-1
Perfluorotridecanoic Acid	PFTrDA	72629-94-8
Perfluorotetradecanoic Acid	PFTeA	376-06-7
Perfluoropropane Sulfonic Acid	PFPrS	423-41-6
Perfluorobutane Sulfonic Acid	PFBS	375-73-5
Perfluoropentane Sulfonic Acid	PFPeS	2706-91-4
Perfluorohexane Sulfonic Acid	PFHxS	355-46-4
Perfluoroheptane Sulfonic Acid	PFHpS	375-92-8
Perfluorooctane Sulfonic Acid	PFOS	1763-23-1
Perfluorononane Sulfonic Acid	PFNS	474511-07-4
Perfluorodecane Sulfonic Acid	PFDS	335-77-3
Perfluorododecane Sulfonic Acid	PFDoS	79780-39-5
4:2 Fluorotelomer Sulfonate	4:2 FTS	414911-30-1
6:2 Fluorotelomer Sulfonate	6:2 FTS	425670-75-3
8:2 Fluorotelomer Sulfonate	8:2 FTS	481071-78-7
10:2 Fluorotelomer Sulfonate	10:2 FTS	120226-60-0
Perfluorobutane Sulfonamide	FBSA	30334-69-1

N-Methylperfluorobutanesulfonamide	MeFBSA	68298-12-4
Perfluorohexane Sulfonamide	FHxSA	41997-13-1
Perfluorooctane Sulfonamide	PFOSA	754-91-6
Perfluorodecane Sulfonamide	FDSA	N/A
N-Ethylperfluorooctane-1-Sulfonamide	NEtFOSA	4151-50-2
N-Methylperfluorooctane-1-Sulfonamide	NMeFOSA	31506-32-8
Perfluorooctane Sulfonamido Acetic Acid	FOSAA	2806-24-8
N-Ethyl Perfluorooctane Sulfonamido Acetic Acid	NEtFOSAA	2991-50-6
N-Methyl Perfluorooctane Sulfonamido Acetic Acid	NMeFOSAA	2355-31-9
N-methyl perfluorooctanesulfonamidoethanol	NMeFOSE	24448-09-7
N-ethyl perfluorooctanesulfonamidoethanol	NEtFOSE	1691-99-2
Hexafluoropropylene Oxide Dimer Acid	HFPO-DA	13252-13-6
4,8-Dioxa-3H-Perfluorononanoate	ADONA	919005-14-4
Perfluoro-3-Methoxypropanoic Acid	PFMPA	377-73-1
Perfluoro-4-Methoxybutanoic Acid	PFMBA	863090-89-5
Perfluoro-3,6-Dioxaheptanoic Acid	NFDHA	151772-58-6
9-Chlorohexadecafluoro-3-Oxanone-1-Sulfonic Acid	9Cl-PF3ONS	756426-58-1
11-Chloroeicosafluoro-3-Oxanonane-1-Sulfonic Acid	11Cl-PF30UdS	763051-92-9
Perfluoro(2-ethoxyethane) Sulfonic acid	PFEESA	113507-82-7
Perfluoro-4-ethylcyclohexane Sulfonic Acid	PFECHS	646-83-3
8-Chloroperfluoro-1-Octanesulfonic Acid	8Cl-PFOS	777011-38-8
3-Perfluoropropyl Propanoic Acid	3:3FTCA	356-02-5
2h,2h,3h,3h-Perfluorooctanoic Acid	5:3FTCA	914637-49-3
3-Perfluoroheptyl propanoic acid	7:3FTCA	812-70-4
2H-Perfluoro-2-dodecenoic acid	FDUEA	70887-94-4
2H-perfluoro-2-decenoic acid	FOUEA	70887-84-2
Bis(perfluorohexyl)phosphinic acid	6:6PFPI	40143-77-9
(Heptadecafluorooctyl)(tridecafluorohexyl) Phosphinic Acid	6:8PFPI	610800-34-5
Bis(perfluorooctyl)phosphinic acid	8:8PFPI	40143-79-1
N-(3-dimethylaminopropan-1-yl) perfluoro-1-hexanesulfonamide	N-AP-FHxSA	50598-28-2

Attachments: 1. Table summarizing side-by-side results
2. EGLE lab report
3. Merit lab report
4. Cyclopure lab report



STATE OF MICHIGAN
DEPARTMENT OF
ENVIRONMENT, GREAT LAKES, AND ENERGY
REMEDIATION AND REDEVELOPMENT DIVISION



GRETCHEN WHITMER
GOVERNOR

PHILLIP D. ROOS
DIRECTOR

October 15, 2025

Elevation Distribution LLC
5848 E 30 Rd
Cadillac, MI 49601

Dear Elevation Distribution LLC:

Thank you for being one of 20 residents/businesses in the Cadillac community to participate in the PFAS comparability study. These results will be very helpful to the Michigan PFAS Action Response Team (MPART)/Department of Environment, Great Lakes, and Energy (EGLE) and Cyclopure to understand the comparability of using three different sampling methods by the same person or team at the same location and as close to the same time as possible.

As you may recall, your home/business was sampled on either September 9th or 10th, 2025 at both your indoor and outdoor faucets. The samples were then sent to EGLE Lab, Merit Lab, and Cyclopure for analysis. In this packet you will find 9 total sets of results, along with a spreadsheet summarizing all your results side-by-side. These include:

- One set of results from an **EGLE** test kit taken from the **indoor faucet** at your home/business without running the water first.
- One set of results from a **Merit Laboratory** test kit taken from the **indoor faucet** at your home/business without running the water first.
- One set of results from a **Cyclopure** test kit taken from the **indoor faucet** at your home/business without running the water first.
- One set of results from an **EGLE** test kit taken from the **indoor faucet** at your home/business after allowing the water to run for three minutes.
- One set of results from a **Merit Laboratory** test kit taken from the **indoor faucet** at your home/business after allowing the water to run for three minutes.
- One set of results from a **Cyclopure** test kit taken from the **indoor faucet** at your home/business after allowing the water to run for three minutes.
- One set of results from an **EGLE** test kit taken from the **outside tap** at your home/business after allowing the water to run for three minutes.
- One set of results from a **Merit Laboratory** test kit taken from the **outside tap** at your home/business after allowing the water to run for three minutes.
- One set of results from a **Cyclopure** test kit taken from the **outside tap** at your home/business after allowing the water to run for three minutes.

Please note when reviewing your results that:

- Each lab has its own format/style to present results.
- Merit Laboratory and the EGLE Laboratory use the same EPA-approved method which analyzes for 25 PFAS compounds, while Cyclopure uses their own method and analyzes for 55 PFAS compounds.
- As you may recall from the letter you were sent initially, the purpose of sampling indoors without running the water first was to follow Cyclopure's standard procedure, and the purpose of sampling outdoors after running the water first was to follow EGLE's standard procedure. EGLE's procedure includes flushing the water for three minutes prior to sampling because the sampling goal is to obtain results that reflect what is in the groundwater. Cyclopure's test does not include this flushing step to reflect concentrations in water that homeowners may be drinking immediately, rather than what is in the groundwater. As a result of these differences, you may see some variation in your indoor vs outdoor results.
- The purpose of this study was to determine if we could get reasonably similar results from each of the three laboratories. Because labs are measuring these compounds at very small amounts, (i.e. parts per trillion) we would consider results that are within a few parts per trillion of each other to be reasonably similar.
- For your convenience, in the Attachment 1 Table we have included your original Cyclopure self-test kit sample results collected outside the scope of this study.

In the coming weeks, you will be receiving a copy of the comparability study report highlighting our overall findings and conclusions without any addresses included.

If you have any questions about your results/the comparability study, please contact Miranda Triolet, EGLE, at 517-290-2201 or TrioletM@michigan.gov.

If you have any health-related questions, please contact Joshua Lee, MDHHS Toxicologist, at 517-243-9522 or LeeK28@michigan.gov.

Thank you again for participating in this comparability study.

Sincerely,

Miranda Triolet

Miranda Triolet
Departmental Analyst, EGLE